




CONNECTING THE WIRES

PREPARATION

Before installation, please check the installation method is proper for the model of car.

1 Connect to the Power and RPM signal




Explanation of wires

Color	Wiring place	Details
Red	IGN	12V with key switch ON (or Normal power)
Black	GND	Screw to gain earth, etc
White	TA	RPM signal
Orange	Illumi	12V with parking lights ON

Orange wire

(There is usually no need to make wire)

This wiring is to use the lowest brightness for the shift lamp when only the parking lights are on.





! at times like this
When another device is already connected to the RPM signal from the ECU

... and that device works properly keep that wiring.

... and the meter or other device stops working properly or sometimes becomes unstable disconnect from the ECU wire and get the RPM from the minus terminal of ignition coil or diagnosis. (Follow the directions as written below)

! at times like this
To get the RPM signal from other than the ECU




When connecting the RPM signal to the ignition coil or diagnosis and the indicated rpm on the meter may be obviously lower than the actual rpm as shown on tachometer

Ex : For a 6 cylinder car, the reading should be 3000 rpm, but display shows 500 rpm.



This may be caused by the individual wiring system of that model of car. Change the cylinder setting to "1". (See "SETTINGS A" for details.)

! at times like this
If you are not using the diagnostic monitor connector
If you are wiring directly cut off and insulate all wires at the base of the OBD2 connector.




! at times like this
When use in conjunction with 3-drive or other PIVOT diagnostic monitor connected product (※2)
For details about using in combination with products that use another company's diagnostic monitoring connectors please see our Web Site at http://pivotip.com/information/obd_conjunction-e.html.

⚠ Insert while the engine is running
In order to prevent making mistakes when inserting the coupler, make sure to insert while the engine is running.



※3 Remove the red and green insulation caps and insert the male connector.


Preparation
When use in conjunction with other PIVOT product (※2), cut the wires coming from the OBD2 connector and properly connect the wires using a connector.



2 Connect to the Shift Lamp


●RL-Z

Insert the 4p coupler from the shift lamp into the terminal at the back of the controller.




●RL-X


Insert the 2p coupler from the shift lamp into the 2p coupler at the back of the controller.



[REFERENCE 1] Notes about using the OBD2 connector




[REFERENCE 2] How to use the connectors





[REFERENCE 3]

How to use provided earth terminal




FASTENING THE PRODUCTS

Install in an easy-to-view location.



BASIC OPERATION

Basic flow of operations for REV LAMP. For details about settings see each [SETTINGS].



SETTINGS



All settings are made using the switches and display on the controller.

SETTING A Cylinder Number Setting

Set the cylinder number for the car being used.

- Press the MODE switch for 5 seconds during the key switch ON (engine not running)
- Cylinder display** Ex) **P4**
 (The factory default setting is for a four-cylinder engine)
- Press the switch to change the pattern and set to the proper one.

Turn **P4** ▷ **P5** ▷ **P6** ▷ **P8** ▷ **PA** ▷ **P1** ▷ **P2** ▷ **P3**

Patterns for cylinder settings display

Display	Number of cylinders	Car models
P1	1	NISSAN (FAIRLADY Z Z33) · MAZDA (ATENZA and others) ※
P2	2	MAZDA (RX-8) · SUBARU (early type of PLEO and others) ※
※For one and two cylinder engines, set the signal level switch to "Lo". → See "Setting D How to switch signal level" for details.		
P3	3	Three-cylinder
P4	4	Four-cylinder, Rotary engine (RX-7)
P5	5	Five-cylinder
P6	6	Six-cylinder
P8	8	Eight-cylinder
PA	Special A	NISSAN MARCH / CUBE, etc.

※If the engine is a two cycle engine, multiply the number of cylinder by two.
(Ex; For a two-cycle three-cylinder engine the setting would be six.)

- With no operation for 3 seconds
- Display off**

SETTING B Shift lamp brightness setting

The brightness for the Shift Lamp can be adjusted in 5 steps.

(Because the ECO Lamp is dimmed its brightness cannot be adjusted.)

- RPM display** Press the MODE switch for 3 seconds
 While displaying RPM (when SP or Ec mode), press the MODE switch for 3 seconds.
- Ex) **L5** The shift lamp will turn on and the display shows the brightness setting
 (EX: Highest Brightness)
- Press the SET / MODE switch
 The display will change with each pressing of the switch.
- With no operation for 3 seconds
- RPM display**

Each pressing will change the brightness.

Dark **L1** ▷ **L2** ▷ **L3** ▷ **L4** ▷ **L5** **Bright**

SETTING C RPM Settings

Make RPM setting for turning on the Shift Lamp and the ECO Lamp.

Mode	Changing item	Setting range
SP	Shift Point	2000 - 9900rpm (100rpm unit)
Ec	ECO Warning Point	1500 - 4000rpm (100rpm unit)

- RPM display** Press the SET switch
 While displaying RPM (when SP or Ec mode), press the SET switch once.
- After displaying Sp or Ec
 Ex) **35** **Current setting display**
 (Ex; 3500rpm)
- Press the switch to change the RPM setting
 Pressing the SET button one time will decrease the RPM setting by 100 rpm; pressing the MODE button will increase the setting by 100 rpm.
 ※Holding down the either button will rapidly change the setting.
- With no operation for 3 seconds
- RPM display**

SETTING D Switching the signal level

Changes are only necessary for those car models listed below.

NISSAN (FAIRLADY Z Z33) · MAZDA (after 2002) · MITSUBISHI (COLT and others) · SUBARU (early type of PLEO and others)
 ※See the "ECU Wiring Diagram List" for details.

- Press the SET switch for 3 seconds during the key switch ON (engine not running)
- Display H, or L**
- Press the SET / MODE switch
 The display will change with each pressing of the switch.
H If the generic car **L** If the level is small
- With no operation for 3 seconds
- Display off**

TROUBLESHOOTING

Trouble	Possible Causes	Possible Solutions
With the engine running the controller does not show the rpm.	Poor connection of each wire.	Check the wire connections or conditions.
	Poor connection of OBD2 connector.	Check the coupler connections or conditions.
	The signal detection level is not correct.	See page 4 [SETTING D] and [ECU Wiring Diagram List], make any necessary changes.
The car's tachometer and the REV LAMP reading are very different.	The cylinder setting is wrong.	Due to difference in accuracy, readings may not be the same as those on the standard tachometer. See page 4 [SETTING A] and make any necessary changes.
	The signal detection level is not correct.	See page 4 [SETTING D] and [ECU Wiring Diagram List], make any necessary changes.
The shift lamp or ECO Lamp does not light up.	The engine rpm has not reached the set shift point.	See page 4 [SETTING C] and make any necessary changes in the rpm point.
	Poor connection of 4p or 2p coupler cord.	Check the wire connections or conditions.
Even with the parking lights on, brightness of the shift lamp does not decrease.	Poor connection of orange wire (12V with parking lights ON).	Check the orange wire connections or conditions.
	The shift lamp brightness setting is set too low.	See page 4 [SETTING B], please check the setting.
The display of the controller is operating even when the engine has been stopped.	Noise from the car (door locks and so on) may cause it to temporarily operate.	If the operation is only temporary it is not a malfunction; but if it still causes worry cut the red wire in the OBD2 connector and connect it to IGN.
The auto-power window function and/or other electronic devices are re-set.	This is due to the minus terminal on the battery being disconnected.	Re-connect the minus terminal and follow re-setting instructions for any affected devices.